

BNL-113532-2017

#### **Position-Sensitive Virtual Frisch-Grid (VFG) Gamma Ray Detectors for Safeguard Applications**

**Aleksey Bolotnikov** 

January 2017

Nonproliferation and National Security Department Radiation Detector and Nonproliferation R&D Group

**Brookhaven National Laboratory** 

U.S. Department of Energy USDOE National Nuclear Security Administration (NNSA), Office of Defense Nuclear Nonproliferation (NA-20)

Notice: This manuscript has been authored by employees of Brookhaven Science Associates, LLC under Contract No. DE-SC0012704 with the U.S. Department of Energy. The publisher by accepting the manuscript for publication acknowledges that the United States Government retains a non-exclusive, paid-up, irrevocable, world-wide license to publish or reproduce the published form of this manuscript, or allow others to do so, for United States Government purposes.

#### DISCLAIMER

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, nor any of their contractors, subcontractors, or their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or any third party's use or the results of such use of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof or its contractors or subcontractors. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

## Position-sensitive virtual Frisch-grid (VFG) Gamma Ray Detectors for Safeguard Applications

Presented at the annual review January 24th, 2017

Principal Investigator: Aleksey Bolotnikov Point of Contact: Peter Vanier



a passion for discovery





- <u>BNL team</u>: G. S. Camarda, Y. Cui, R. Gul, G. De Geronimo, J. Fried, A. Hossain, L. Ocampo, C. Salwen, E. Vernon, G. Yang, and R. B. James (SRNL)
- <u>BNL students</u>: M. Petryk, S. Cheng, A. McGilloway, C. Cherches, M. Siegel and R. Gallagher
- External Collaborator: FLIR Systems, Inc.

<u>Subcontractors</u>: Redlen and eV Products



## Introduction

- Goal: Incorporate an array of the novel position-sensitive virtual Frisch-grid CdZnTe detectors into the existing FLIR instrument (R200)
- Motivation: need for better gamma-ray detectors with enhance spectral resolution, efficiency and functionalities
- FLIR offers today three handheld instruments (all used by IAEA inspectors)



Nal(Tl) scintillator ~6% at 662 keV

IdentiFINDER R300 (formerly nanoRAIDER)



IdentiFINDER R200 (recently introduced)



We propose to upgrade this device because has the most recent DAQ and signal processing platform

Hemispherical CZT detectors, 2-3% at 662 keV

CsI scintillator ≤ 7.5% at 662 keV

These devices are compact, rugged, very reliable, have great functionality and convenient user interface but have limited spectral resolution



## **Goal - Integrate VFG detectors into FLIR R200**



U.S. Department of Energy

## **Current status**

- New adaptor board -- Complete
- We worked with FLIR closely on this project to make sure that the adaptor board will fit into R200 device -- Complete
- FLIR is to modify their acquisition board of R200 to the new VFG-based devices – Work in progress (FLIR is waiting for CRADA)
- A bridge board for testing the adaptor board with BNL's acquisition system -- Complete
- The bridge board was used to test the adaptor and verify that it works as designed Complete
- CRADA has been approved! (InCRADAble news)
- Preparation for testing the current prototype at SRNL (and eventually the first FLIR prototype) – In progress
- Two new tasks:
- Develop an algorithm for position reconstruction -- Complete
- Test a linear (1x6) array of VFG detectors -- Complete

Bridge board





## Examples of commonly used CZT detectors today

- Today, CZT detectors is a proven technology: high-efficiency, excellent energy and position resolutions, operate at ambient temperature
- They are particularly beneficial in compact handheld instruments for field applications
- However, crystal defects, which are present even in the best quality CZT crystals, affect production yield and increase cost of CZT detectors

Examples of large-volume CZT detectors available today



Detectors rely on the highest quality CZT crystals to achieve their best performances  $\rightarrow$  Such crystals have low production yields and are very expensive! Maximum thickness is limited by 15 mm!

## Arrays of virtual Frisch-grid (drift) detectors

- To overcome the high cost and low availability of big CZT crystals we propose arrays of small cross-section, up to 7x7 mm<sup>2</sup>, but long, up to 5 cm, detectors
- Such crystals have much higher production-yield and lower; typically cut from the crystals rejected by other costumers
- The bars are configured as position-sensitive virtual Frisch-grid detectors:

Positionsensitive virtual Frischgrid detector



We attached 4 position-sensing pads (<u>non-contacting</u> electrodes) for measuring X-Y coordinates of interaction points

The cathode signals are used to measure drift times to evaluate Z coordinates, like in TPC

Virtually grounded pads produce the Frischgrid effect (as if a real grid were placed inside the detector) Cathode



Anode

Examples of CZT bars



Can be used in large-area arrays or in small, 2x2, arrays that we proposed for FLIR instruments



NATIONAL LA

This design was originally proposed for noble gas detectors by V. Chernaytin et al. First applied to CZT detectors by G. Montemont (LETI) and D. McGregor (Kansas State University)

## Virtual Frisch-grid effect produced by grounded pads

Pulse-height spectra measured with shielded and unshielded detectors

Unshielded detector Blue – unshielded (planar detector) 2500 Red – shielded 2000 Counts per channel Detector with <1.5% shielding pads FWHM Test 500 pulser 0 800 0 400 1200 1600 2000

5x5x10 mm<sup>3</sup> detector

Channels



## X-Y spatial resolution of position-sensitive virtual Frisch-grid detectors

6x6x15 mm<sup>3</sup> virtual Frisch-grid detector detector irradiated with a <sup>241</sup>Am source

Image of a 1-mm Tungsten slit collimator placed above the cathode

6x6 mm<sup>2</sup> area



 High-resolution position sensing is the most important feature of our detectors

- It allows us to correct the detector response nonuniformities caused by crystal defects
- Benefits of this approach:
  - Employ unselected low-cost CZT crystals and, at the same time, achieve a high energy resolution
  - Use longer crystals (higher detection efficiency)
  - Operate detectors at lower biases



## Position-sensitive virtual Frisch-grid detectors (CZT drift detectors)

3D positionsensitive device

- Because defects locations are fixed, the response non-uniformity is caused by random distributions of interaction points  $\rightarrow$  Such variations can be corrected if the locations of interaction points are known with sufficient accuracy
- Position information allows us to virtually segment a detector into small voxels and equalize responses from each voxel
- A 3D correction matrix (lookup table) is generated during calibration



Brookhaven Science Associate (calibration step) and use it to correct measured signals

U.S. Department of Energy



## How we fabricate detectors and arrays

For insulation and mechanical protection of CZT crystals, we use the ultra-thin polyester shrink tube (Advanced Polymer, Inc.)

This material has very high dielectric strength and resistivity

Dielectric strength: > 4,000 V/mil Volume Resistivity: 10<sup>18</sup> Ohm-cm, Surface Resistivity: 10<sup>14</sup> Ohm/square, Dielectric Constant: 3.3

A crystal and two aluminum bars are inserted inside the tube and put inside hot water (~80 C) for 2-3 min. The remaining tube is cut and edges are trimmed.

> Encapsulated crystal inside the shrink tube









## Experimental setup for testing virtual Frisch-grid detectors





Test box

Currently, we employ the existing ASIC and DAQ developed for the conventional CZT arrays which has many limitations in the case of position-sensitive detectors

Its architecture is identical to the H3D ASIC developed by the BNL's Instrumentation Division in collaboration with the University of Michigan

For the position-sensitive detector arrays we are currently developing the new ASIC which will be available next year



# Typical charge signals (after preamps) generated on the cathode, anode, and sensing pads



## Testing a 4x4 array prototype (NA22 project)



#### **Detectors housing**



Pad connections in a 4x4 module



16 anodes 4 cathodes 32 sensing pads Brooknaver colonice resociates U.S. Department of Energy Incident photon

Ambiguity problem in the case of multiple interaction points







### Best results from 20, 30, 40, and 50 mm thick detectors



## We can correct full spectra (not a single gamma-line)



NATIONAL LABORATORY

## Broad energy range

Increased efficiency allows detection of energetic gamma rays



BROOKHAVEN NATIONAL LABORATORY

## Pu-239

#### 6x6x20 mm<sup>3</sup> position sensitive detector



BROOKHAVEN NATIONAL LABORATORY

## We can make thicker detectors biased at lower voltages



Can operated at reduced bias but the electric field must be above a certain limit (~1000 V/cm ) to attain <1% resolution (~2500 V/cm in pixel detectors)

BROOKHAVEN

## Temperature dependence of energy resolution





## **Position sensing**



 $A_{x}^{1} \leftarrow (x, y) \rightarrow A_{x}^{2}$   $A_{x}^{1} \leftarrow (x, y) \rightarrow A_{x}^{2}$   $A_{x}^{2} \rightarrow A_{x}^{2}$ 

If assume a linear approximation for the response function we get the well known the center of gravity method

$$A_x^+ + A_x^-$$

$$Y = \frac{A_y^2}{A_y^1 + A_y^2}$$

 $X = \frac{A_x^2}{1}$ 

## We use linear approximation for signal corrections

Brookhaven Science Associates U.S. Department of Energy

Reverse response functions give two independent estimates for *X* and two estimates for *Y* 

How to evaluate the weighs?

Here is the standard approach based on statistical errors

...but systematic errors in the response function could be more important → this needs a better understanding Response function  $A_i = R(x, y)$   $X_1 = R^{-1} \left( A_x^1, A_y^1, A_y^2 \right)$   $X_2 = L - R^{-1} \left( A_x^2, A_y^1, A_y^2 \right)$ 

 $X = \frac{X_1 W_1 + X_2 W_2}{W_1 + W_2}$ 

$$W = \frac{1}{\sigma_x^2}$$

$$\sigma_{x1}^2 = \left(\frac{\partial R^{-1}}{\partial A_x^1}\right)^2 \sigma_A^2$$

$$\sigma_{x2}^2 = \left(\frac{\partial R^{-1}}{\partial A_x^2}\right)^2 \sigma_A^2$$

BROOKHAVEN

## Evaluating the response functions, *R*, and inverse response functions, $R^{-1}$

- Response functions can be directly measured, e.g., using a pulsed laser
- Alternatively, they can be evaluated using iterative fitting process of the experimental data obtained with uncollimated <sup>137</sup>Cs source
- As a starting point we use a linear approximation (first order)

Response function is a dependence of the pad signal versus position of the electron cloud

Evaluated response functions (second order approximation)



U.S. Department of Energy

XY distributions of interaction events measured for a 6x6x20 mm<sup>3</sup> detectors using 2-, 3-, and 4- pads readout



U.S. Department of Energy

NATIONAL LABORATORY

XY response distribution (662-keV photopeak position) measured for a 6x6x20 mm<sup>3</sup> detector using 2-, 3-, and 4-



## 2x2 array modules for the first prototype





4 anodes 1 common cathode 8 channels for 16 sensing pads Total: 24 readout channels

As a temporary solution use the existing 36-channel ASIC The new ASIC is been developed by BNL's Instrumentation



# Cs-137 spectra measured with array #1 (6x6x20 mm<sup>3</sup> detectors)



Brookhaven S U.S. Departme

### Cs-137 spectra measured with array #2 (7x7x20 mm<sup>3</sup> detectors)



NATIONAL LABORATORY

## Response maps (based on photopeak positions) evaluated for the 4 7x7x20 mm<sup>3</sup> detectors before XY corrections



Prismatic dislocations are present in Redlen CZT crystals



## Using 2 and 3 pads (instead of 4) to solve ambiguity problem



U.S. Department of Energy

## Testing a linear 6-detector array

Linear array of 6 six 5x7x25 mm<sup>3</sup> detectors







## Pulse-height spectra from <sup>137</sup>Cs (3500 V)



## Pulse-height spectra from <sup>137</sup>Cs (3500 V)



## Response maps evaluated for the detectors from the array



**Prismatic dislocations** 



## Pulse-height spectra from <sup>134</sup>Cs (2500 V)



## Pulse-height spectra from <sup>133</sup>Ba (2500 V)



## Combined pulse-height spectra of <sup>133</sup>Ba (2500 V)





Advantages and drawbacks of the proposed detectors

- Advantages:
  - Large thickness (high efficiency for high-energy gamma rays
  - Good energy and position resolutions
  - Possibility of using standard-grade CZT material (lower cost)
  - Operate at lower HV bias
- Drawbacks:
  - Higher leakage current (electronic noise)
  - Potential polarization in the high gamma-flux conditions (this needs to be tested during the test at SRNL)



- We demonstrated 2x2 and 1x6 array prototypes of position-sensitive virtual Frisch-grid detectors and readout electronics for a new generation of handheld instruments for safeguard application
- We will perform a demonstration of a measurement of uranium hexafluoride enrichment at SRNL using the lab prototype
- We work with FLIR to incorporate the arrays and new ASIC into the FLIR instrument
- We will demonstrate the FLIR integrated prototype when available

Acknowledgments

The work was supported by the U. S. Department of Energy, Office of Nonproliferation and International Security, Office of Nuclear Safeguards & Security, Next Generation Safeguards Initiative's Safeguards Technology Development Team (NA-241), and Office of Defense Nuclear Nonproliferation Research & Development (NA-22).

